



NX102-1200

Sysmac NX1 Modular CPU, 5MB program and 33.5MB data memory , built-in EtherCAT (8 servo axes, 4 PTP axes, total 64 EtherCAT nodes), 2 Ethernet ports (OPC-UA and EtherNet/IP)

Specifications

Controller functionality	Motion control, OPC-UA, Position control, Sequence control
Max. number of synchronous axes	8
Max. number of PTP axes	4
Max. number of axes (incl. virtual)	15
Primary task cycle time	1 ms
Program memory	5 MB
Variables memory	33.5 MB
Communication port(s)	EtherCAT Master, EtherNet/IP, Ethernet TCP/IP
Communication option(s)	Serial RS-232C, Serial RS-422, Serial RS-485
Max. number of remote I/O nodes	64
I/O system	NX I/O Bus
Max. number of expansion units	32
Product Height (unpacked)	100 mm
Product Width (unpacked)	66 mm
Product Depth (unpacked)	100 mm
Product Weight (unpacked)	470 g

Accessories



CJ1W-BAT01

Battery for CJ1M PLCs



GX-JC03

3-port EtherCAT Junction module, 24 VDC power supply



GX-JC06

6-port EtherCAT Junction module, 24 VDC power supply



GX-JC06-H

6-port EtherCAT Junction module, 24 VDC power supply, with node switches

HMC-SD493

SD memory card, 4 GB



W4S1-05D

5-port enhanced Ethernet switch

Spare parts

NX-END02

Spare part - End plate for NX1P controller

Downloads

[CAD Library](#)



Data validity check Brochure

EN PDF 202 KB



EAC Mark removal Discontinuation Notice

EN PDF 221 KB



High-speed inspection Brochure

EN PDF 319 KB



Machine Safety Solution Brochure

EN PDF 2.86 MB



NJ-series -[EtherCAT]- ORIENTAL MOTOR aSTEP DC Multi-Axis Drive (AZDXA-KED)

Connection Guide

EN PDF 3.99 MB



NJ-series -[EtherNet/IP]- SMC AMS-S Series

Connection Guide

EN PDF 2.23 MB



NJ-series -[Ethernet TCP/IP]- Hioki LCR Meter (IM3536)

Connection Guide

EN PDF 2.13 MB



NJ/NX-Series CPU Unit Motion Control

Users Manual

EN PDF 19.6 MB



NJ/NX-Series CPU Unit Software

Users Manual

EN PDF 18.9 MB



NJ/NX-Series Instructions

Reference Manual

EN PDF 16.3 MB



NJ/NX-Series Motion Control Instructions

Reference Manual

EN PDF 7.21 MB



NJ/NX-Series OPC UA CPU Units

Users Manual

EN PDF 4.64 MB



NJ/NX-series - [EtherCAT]- CKD ABSODEX driver (AX9000TS/TH-U5)

Connection Guide

EN PDF 1.73 MB



NJ/NX-series - [EtherCAT]- Denso Wave RC9 Robot

Connection Guide

EN PDF 2.72 MB



NJ/NX-series - [EtherCAT]- Festo CPX- AP-I

Connection Guide

EN PDF 1.37 MB



NJ/NX-series - [EtherCAT]- Festo MSE6-E2M

Connection Guide

EN PDF 1.6 MB



NJ/NX-series - [EtherCAT]- HMS Anybus X-gateway ABX

Connection Guide

EN PDF 1.96 MB



NJ/NX-series - [EtherCAT]- Hitachi ADV-Series AC Servo Drives

Connection Guide

EN ZIP 4.29 MB



NJ/NX-series - [EtherCAT]- Inficon gauge (BPG402-SE)

Connection Guide

EN PDF 1.22 MB



NJ/NX-series - [EtherCAT]- Kashiwama Dry Vacuum Pump (E- CAT01 1ch)

Connection Guide

EN PDF 1.59 MB



NJ/NX-series - [EtherCAT]- Kashiwama Dry Vacuum Pump (E- CAT02)

Connection Guide

EN PDF 1.61 MB



NJ/NX-series - [EtherCAT]- Kawasaki F-series Robot Controller F60

Connection Guide

EN PDF 2.32 MB



NJ/NX-series - [EtherCAT]- Mitutoyo EJ-102N Linear Gage Counter

Connection Guide

EN PDF 1.63 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]- CKD Sensor (PPX series)

Connection Guide

EN PDF 2.43 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-CKD Sensor (WFC series)

Connection Guide

EN PDF 2.75 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-CKD WFK2 Flow sensor

Connection Guide

EN PDF 2.09 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-MTS Sensors (E-Series)

Connection Guide

EN PDF 2.4 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-PATLITE Beacon (NE-IL)

Connection Guide

EN PDF 2.02 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-PATLITE Tower (LR6-IL)

Connection Guide

EN PDF 2.08 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-SMC (ISA3-xxx)

Connection Guide

EN PDF 2.61 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-SMC (xSE20Bx-L(-M/-P)-x)

Connection Guide

EN PDF 2.13 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-SMC ITVx000/-IO*

Connection Guide

EN PDF 1.89 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-SMC Servo 24VDC (JXCL1)

Connection Guide

EN PDF 2.23 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-Schmalz Ejector (SCPSi)

Connection Guide

EN PDF 2.4 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-ifm (O5D10x/O5D15x)

Connection Guide

EN PDF 2.42 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-ifm (PN7x94)

Connection Guide

EN PDF 2.72 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-ifm (TN24xx)

Connection Guide

EN PDF 2.74 MB



NJ/NX-series - [EtherCAT]- NX-ECC + NX-ILM400 -[IO-Link]-ifm TR7439 Pt100/1000

Connection Guide

EN PDF 2.43 MB



NJ/NX-series - [EtherCAT]- Nidec Sankyo S-FLAG II Series AC Servo (DB6xx41)

Connection Guide

EN PDF 2.65 MB



NJ/NX-series - [EtherCAT]- NittoSeiko SD600T driver controller

Connection Guide

EN PDF 2.18 MB



NJ/NX-series - [EtherCAT]- ORIENTAL MOTOR Stepper Motor (AZ-series)

Connection Guide

EN PDF 2.89 MB



NJ/NX-series - [EtherCAT]- Oriental Motor Alpha STEP AZ series

Connection Guide

EN PDF 3.47 MB



NJ/NX-series - [EtherCAT]- SANYO DENKI AC Servo SANMOTION R 3E MODEL TYPE S

Connection Guide

EN PDF 3.08 MB



NJ/NX-series - [EtherCAT]- SANYO DENKI AC Servo SANMOTION R ADVANCED MODEL TYPE F

Connection Guide

EN PDF 3.61 MB



NJ/NX-series - [EtherCAT]- SHIMADZU Power Unit for Turbo Molecular Pump (TMP)

Connection Guide

EN PDF 1.29 MB



NJ/NX-series - [EtherCAT]- SICK Absolute Encoder (AFS60/AFM60)

Connection Guide

EN PDF 1.52 MB



NJ/NX-series - [EtherCAT]- Schmalz Compact Terminal (SCTSi-ECT)

Connection Guide

EN PDF 1.33 MB



NJ/NX-series - [EtherCAT]- Unipulse Weighing Indicator (FC400-ECT)

Connection Guide

EN PDF 1.72 MB



NJ/NX-series - [EtherCAT]- Weidmüller Remote I/O System (u-remote IP20)

Connection Guide

EN PDF 1.8 MB



NJ/NX-series - [EtherCAT]- YASKAWA Sigma 7-series

Connection Guide

EN ZIP 3.77 MB



NJ/NX-series -[EtherNet TCP/IP]- HIOKI Battery HiTESTER (BT356[A])

Connection Guide

EN PDF 2.27 MB



NJ/NX-series - [EtherNet/IP]- Balluff BNI EIP-50x-105-Z015

Connection Guide

EN PDF 3.35 MB



NJ/NX-series - [EtherNet/IP]- CKD ABSODEX Driver (AX9000TS/TH-U6)

Connection Guide

EN PDF 1.71 MB



NJ/NX-series - [EtherNet/IP]- HMS Anybus Communicator

Connection Guide

EN PDF 1.51 MB



NJ/NX-series - [EtherNet/IP]- HMS Anybus X-gateway

Connection Guide

EN PDF 1.79 MB



NJ/NX-series - [EtherNet/IP]- Hilscher netTAP NT100 Gateway (NT 100-RE-DN)

Connection Guide

EN PDF 3.5 MB



NJ/NX-series - [EtherNet/IP]- IAI RCON system & MCON / MCON / MSEP Controller

Connection Guide

EN PDF 1.9 MB



NJ/NX-series - [EtherNet/IP]- KOGANEI Manifold Solenoid Valve (F Series)

Connection Guide

EN PDF 2.43 MB



NJ/NX-series - [EtherNet/IP]- Magnescale Digital Gauge (MG80-EI)

Connection Guide

EN PDF 1.84 MB



NJ/NX-series - [EtherNet/IP]- Nordson ProBlue Adhesive Melters

Connection Guide

EN PDF 2.61 MB



NJ/NX-series - [EtherNet/IP]- ORIENTAL MOTOR Alpha STEP Compatible Driver (AZD-xEP)

Connection Guide

EN PDF 1.82 MB



NJ/NX-series - [EtherNet/IP]- SMC Solenoid Valve (SI Unit EX260-SEN#)

Connection Guide

EN PDF 1.65 MB



NJ/NX-series - [EtherNet/IP]- Schmalz K.K. Compact Terminal (SCTSi-EIP)

Connection Guide

EN PDF 1.69 MB



NJ/NX-series - [EtherNet/IP]- Unipulse FC400-EIP

Connection Guide

EN PDF 2.26 MB



NJ/NX-series - [EtherNet/IP]- Unipulse FS2000-EIP

Connection Guide

EN PDF 3.38 MB



NJ/NX-series - [EtherNet/IP]- ifm IO-Link master (AL1322)

Connection Guide

EN PDF 3.18 MB



NJ/NX-series - [EtherNet/IP]- ifm IO-Link master (AL1920)

Connection Guide

EN PDF 3.07 MB



NJ/NX-series Machine Automation Controller

Brochure

EN PDF 2.3 MB



NJ/NX-series Machine Automation Controller Database Connection CPU Unit

Brochure

EN PDF 1.34 MB



NJ/NX/NY-series Sysmac Library User's Manual for Safety System Monitor Library Users Manual

Users Manual

EN PDF 922 KB



NX-series -[Ethernet TCP/IP]- V330-F, V430-F Code Readers

Connection Guide

EN PDF 2.89 MB



NX-series -[RS-232C]- V320-F, V420-F, V430-F Code Readers

Connection Guide

EN PDF 2.48 MB



NX1 Machine Automation Controller Datasheet

EN PDF 2.92 MB



NX1 Machine Automation Controller Brochure

EN PDF 7.11 MB



NX1-series + NX-ILM400 -[IO-Link]- SMC D-MP# Actuator Position Sensor Connection Guide

EN PDF 1.88 MB



NX1-series + NX-ILM400 -[IO-Link]- SMC Digital Flow Switch Connection Guide

EN PDF 2.58 MB



NX102 CPU Unit Technical Manual

EN PDF 7.24 MB



OEN Sample and Library files Connection Guide

EN ZIP 9.25 MB



Omron GX-JC0x-x EtherCAT Junction Box EtherCAT ESI file

EN ZIP 3.36 KB



Quality gate for each process Brochure

EN PDF 167 KB



Redundancy and Motion Safety Flyer

EN PDF 960 KB



SYSMAC-XR020 MQTT Communications Library Flyer

EN PDF 621 KB



Sysmac: A Fully Integrated Platform Brochure

EN PDF 19.1 MB