TF6600 | TC3 RFID Reader Communication

RFID Reader Communication erlaubt das Ansprechen verschiedener RFID-Reader über eine serielle Schnittstelle. Mit dieser Bibliothek steht ein generelles abstraktes Interface zur Verfügung, das für alle Reader genutzt werden kann. Die Anpassung an einen speziellen Reader ist durch eine Konfigurationseinstellung einfach durchzuführen.

Technische Daten	TF6600
Benötigt	TC1200
Zielsystem	Windows XP, Windows 7/8/10, Windows CE

Bestellangaben	
TF6600-0020	TC3 RFID Reader Communication, Plattform 20 (Economy)
TF6600-0030	TC3 RFID Reader Communication, Plattform 30 (Economy Plus)
TF6600-0040	TC3 RFID Reader Communication, Plattform 40 (Performance)
TF6600-0050	TC3 RFID Reader Communication, Plattform 50 (Performance Plus)
TF6600-0060	TC3 RFID Reader Communication, Plattform 60 (Mid Performance)
TF6600-0070	TC3 RFID Reader Communication, Plattform 70 (High Performance)
TF6600-0080	TC3 RFID Reader Communication, Plattform 80 (Very High Performance)
TF6600-0081	TC3 RFID Reader Communication, Plattform 81 (Many-core 5…8 Cores)
TF6600-0082	TC3 RFID Reader Communication, Plattform 82 (Many-core 9…16 Cores)
TF6600-0083	TC3 RFID Reader Communication, Plattform 83 (Many-core 17…32 Cores)
TF6600-0084	TC3 RFID Reader Communication, Plattform 84 (Many-core 33…64 Cores)
TF6600-0090	TC3 RFID Reader Communication, Plattform 90 (Other)
TF6600-0091	TC3 RFID Reader Communication, Plattform 91 (Other 5…8 Cores)
TF6600-0092	TC3 RFID Reader Communication, Plattform 92 (Other 9…16 Cores)
TF6600-0093	TC3 RFID Reader Communication, Plattform 93 (Other 17…32 Cores)
TF6600-0094	TC3 RFID Reader Communication, Plattform 94 (Other 33…64 Cores)