



R88M-1L2K030C-BS2

1S AC servo motor, 2 kW, 400 VAC, 3000 rpm, 6.37 Nm, absolute encoder, with brake

Specifications

Servo control method	EtherCAT
Drive supply voltage	400 V three phase
Rated output	2 kW
Rated speed	3000 r/min
Rated torque	6.37 Nm
Peak torque	19.1 Nm
Encoder type	Absolute without battery
Encoder resolution	23 Bit
Motor with brake	✓
Motor with oil seal	✗
Flange size square (LC)	100 mm
Shaft diameter	19 mm
Shaft with key	✓
Shaft with tap	✓
Product Weight (unpacked)	8100 g

Fits to



R88D-1SN20F-ECT
1S servo drive, EtherCAT type, 2 kW, 3~ 400 VAC



R88D-1SN20F-ECT-51
1S-51 servo drive with STO, SS1 and SLS safety, EtherCAT type, 2 kW, 3~ 400 VAC

Accessories



R88A-CA1E001-5BF-E

1S series servo motor power cable, 1.5 m, with brake, 400 V: 400 W to 3 kW



R88A-CA1E003BF-E

1S series servo motor power cable, 3 m, with brake, 400 V: 400 W to 3 kW



R88A-CA1E005BF-E

1S series servo motor power cable, 5 m, with brake, 400 V: 400 W to 3 kW



R88A-CA1E010BF-E

1S series servo motor power cable, 10 m, with brake, 400 V: 400 W to 3 kW



R88A-CA1E015BF-E

1S series servo motor power cable, 15 m, with brake, 400 V: 400 W to 3 kW



R88A-CA1E020BF-E

1S series servo motor power cable, 20 m, with brake, 400 V: 400 W to 3 kW



R88A-CR1B001-5NF-E

1S series servo encoder cable, 1.5m, 230V: 900W-1.5kW, 400V: 400W-15kW



R88A-CR1B003NF-E

1S series servo encoder cable, 3m, 230V: 900W-1.5kW, 400V: 400W-15kW



R88A-CR1B005NF-E

1S series servo encoder cable, 5m, 230V: 900W-1.5kW, 400V: 400W-15kW



R88A-CR1B010NF-E

1S series servo encoder cable, 10m, 230V: 900W-1.5kW, 400V: 400W-15kW



R88A-CR1B015NF-E

1S series servo encoder cable, 15m, 230V: 900W-1.5kW, 400V: 400W-15kW



R88A-CR1B020NF-E

1S series servo encoder cable, 20m, 230V: 900W-1.5kW, 400V: 400W-15kW



R88A-SC021S-E

1S series cable clamp B. Used in 400 V drives and 230 V (from 1.5 kW to 3 kW)

CAD Library



1S Series Users Manual

EN PDF 23 MB



1S Series - Expanded with high capacity range: 4 - 15 kW

Flyer

EN PDF 1.64 MB



1S Series Incremental Encoder Type Users Manual

Users Manual

EN PDF 6.34 MB



1S Series Multi-axis Setup and Tuning Getting Started Guide

EN PDF 7.86 MB



1S Servo System Brochure

EN PDF 25.6 MB



1S-series Servos for EN Instruction Manual

EN PDF 3.39 MB



AC Servomotor_Servo Drives - Replace Guide

Replacement guide

EN PDF 4.74 MB



EAC Mark removal Discontinuation Notice

EN PDF 221 KB



Motor Sizing Tool Operation Manual

EN PDF 3.83 MB



R88M-1_1S-series Servo Motor

Datasheet

EN PDF 1.57 MB



Redundancy and Motion Safety

Flyer

EN PDF 960 KB



Sysmac Catalogue

EN PDF 43.5 MB



Sysmac: A Fully Integrated Platform

Brochure

EN PDF 19.1 MB



Using R88A-CA1G power cables

Technical Information

EN PDF 1.6 MB



motor_sizing_tool_v1.80.1.21 Configurator

EN ZIP 37.8 MB