



 PRODUCT-DETAILS

3ADT313900R1501

-; SDCS-CON-4 COAT-ROHS CONTROL BOARD



General Information

| | |
|----------------------|---------------------------------------|
| Product ID | 3ADT313900R1501 |
| ABB Type Designation | - |
| Catalog Description | -; SDCS-CON-4 COAT-ROHS CONTROL BOARD |

Additional Information

| | |
|--------------------------------|--|
| ABB Type Designation | - |
| CN8 | 85371098 |
| Core Credit | 0.00 |
| Country or Territory of Origin | China |
| | Hong Kong Special Administrative Region of China |
| Customs Tariff Number | 85049090 |
| Frame Size | Spare_Parts |
| Gross Volume | 0.011 m ³ |
| Gross Weight | 0.4 kg |
| Invoice Description | SDCS-CON-4 COAT-ROHS CONTROL BOARD |
| Made To Order | No |
| Minimum Order Quantity | 1 piece |

| | |
|------------------------------|---|
| Order Multiple | 1 piece |
| Package Level 1 Gross Weight | 0.4 kg |
| Package Level 1 Units | 1 piece |
| Part Type | New |
| Product Name | SDCS-CON-4 COAT-ROHS CONTROL BOARD |
| Product Net Weight | 0.4 kg |
| Product Type | Spare_Parts |
| Quote Only | No |
| Replaced Product ID (OLD) | 3ADT313900R1001 |
| Selling Unit of Measure | piece |
| Stocked At (Warehouses) | Finland Menden, Germany New Berlin, Wisconsin, United States Beijing, China Singapore, Singapore Tokyo, Japan Finland Bangalore, India |
| Technical Information | - |
| WEEE Category | Product Not in WEEE Scope |

Where Used (as a spare part for "Products")

| Identifier | Description | Quantity | Unit Of Measure |
|--------------------|--------------------------|----------|-----------------|
| DCS800-S01-0020-04 | No Description Available | 1 | piece |
| DCS800-S01-0020-05 | No Description Available | 1 | piece |
| DCS800-S01-0045-04 | No Description Available | 1 | piece |
| DCS800-S01-0045-05 | No Description Available | 1 | piece |
| DCS800-S01-0065-04 | No Description Available | 1 | piece |
| DCS800-S01-0065-05 | No Description Available | 1 | piece |
| DCS800-S01-0090-04 | No Description Available | 1 | piece |
| DCS800-S01-0090-05 | No Description Available | 1 | piece |
| DCS800-S01-0125-04 | No Description Available | 1 | piece |
| DCS800-S01-0125-05 | No Description Available | 1 | piece |
| DCS800-S01-0180-04 | No Description Available | 1 | piece |
| DCS800-S01-0180-05 | No Description Available | 1 | piece |
| DCS800-S01-0230-04 | No Description Available | 1 | piece |
| DCS800-S01-0230-05 | No Description Available | 1 | piece |
| DCS800-S01-0290-06 | No Description Available | 1 | piece |
| DCS800-S01-0315-04 | No Description Available | 1 | piece |
| DCS800-S01-0315-05 | No Description Available | 1 | piece |
| DCS800-S01-0405-04 | No Description Available | 1 | piece |
| DCS800-S01-0405-05 | No Description Available | 1 | piece |
| DCS800-S01-0470-04 | No Description Available | 1 | piece |
| DCS800-S01-0470-05 | No Description Available | 1 | piece |
| DCS800-S01-0590-06 | No Description Available | 1 | piece |
| DCS800-S01-0610-04 | No Description Available | 1 | piece |

| | | | |
|--------------------|--------------------------|---|-------|
| DCS800-S01-0610-05 | No Description Available | 1 | piece |
| DCS800-S01-0740-04 | No Description Available | 1 | piece |
| DCS800-S01-0740-05 | No Description Available | 1 | piece |
| DCS800-S01-0900-04 | No Description Available | 1 | piece |
| DCS800-S01-0900-05 | No Description Available | 1 | piece |
| DCS800-S01-0900-06 | No Description Available | 1 | piece |
| DCS800-S01-0900-07 | No Description Available | 1 | piece |
| DCS800-S01-1200-04 | No Description Available | 1 | piece |
| DCS800-S01-1200-05 | No Description Available | 1 | piece |
| DCS800-S01-1500-04 | No Description Available | 1 | piece |
| DCS800-S01-1500-05 | No Description Available | 1 | piece |
| DCS800-S01-1500-06 | No Description Available | 1 | piece |
| DCS800-S01-1500-07 | No Description Available | 1 | piece |
| DCS800-S01-1900-08 | No Description Available | 1 | piece |
| DCS800-S01-2000-04 | No Description Available | 1 | piece |
| DCS800-S01-2000-05 | No Description Available | 1 | piece |
| DCS800-S01-2000-06 | No Description Available | 1 | piece |
| DCS800-S01-2000-07 | No Description Available | 1 | piece |
| DCS800-S01-2050-05 | No Description Available | 1 | piece |
| DCS800-S01-2050-06 | No Description Available | 1 | piece |
| DCS800-S01-2050-07 | No Description Available | 1 | piece |
| DCS800-S01-2500-04 | No Description Available | 1 | piece |
| DCS800-S01-2500-05 | No Description Available | 1 | piece |
| DCS800-S01-2500-06 | No Description Available | 1 | piece |
| DCS800-S01-2500-07 | No Description Available | 1 | piece |
| DCS800-S01-2500-08 | No Description Available | 1 | piece |
| DCS800-S01-3000-04 | No Description Available | 1 | piece |
| DCS800-S01-3000-05 | No Description Available | 1 | piece |
| DCS800-S01-3000-06 | No Description Available | 1 | piece |
| DCS800-S01-3000-07 | No Description Available | 1 | piece |
| DCS800-S01-3000-08 | No Description Available | 1 | piece |
| DCS800-S02-0025-04 | No Description Available | 1 | piece |
| DCS800-S02-0025-05 | No Description Available | 1 | piece |
| DCS800-S02-0050-04 | No Description Available | 1 | piece |
| DCS800-S02-0050-05 | No Description Available | 1 | piece |
| DCS800-S02-0075-04 | No Description Available | 1 | piece |
| DCS800-S02-0075-05 | No Description Available | 1 | piece |
| DCS800-S02-0100-04 | No Description Available | 1 | piece |
| DCS800-S02-0100-05 | No Description Available | 1 | piece |
| DCS800-S02-0140-04 | No Description Available | 1 | piece |
| DCS800-S02-0140-05 | No Description Available | 1 | piece |
| DCS800-S02-0200-04 | No Description Available | 1 | piece |
| DCS800-S02-0200-05 | No Description Available | 1 | piece |
| DCS800-S02-0260-04 | No Description Available | 1 | piece |
| DCS800-S02-0260-05 | No Description Available | 1 | piece |
| DCS800-S02-0320-06 | No Description Available | 1 | piece |
| DCS800-S02-0350-04 | No Description Available | 1 | piece |
| DCS800-S02-0350-05 | No Description Available | 1 | piece |
| DCS800-S02-0450-04 | No Description Available | 1 | piece |
| DCS800-S02-0450-05 | No Description Available | 1 | piece |
| DCS800-S02-0520-04 | No Description Available | 1 | piece |
| DCS800-S02-0520-05 | No Description Available | 1 | piece |
| DCS800-S02-0650-06 | No Description Available | 1 | piece |
| DCS800-S02-0680-04 | No Description Available | 1 | piece |

| | | | |
|---------------------|--------------------------|---|-------|
| DCS800-S02-0680-05 | No Description Available | 1 | piece |
| DCS800-S02-0820-04 | No Description Available | 1 | piece |
| DCS800-S02-0820-05 | No Description Available | 1 | piece |
| DCS800-S02-1000-04 | No Description Available | 1 | piece |
| DCS800-S02-1000-05 | No Description Available | 1 | piece |
| DCS800-S02-0900-06 | No Description Available | 1 | piece |
| DCS800-S02-0900-07 | No Description Available | 1 | piece |
| DCS800-S02-1200-04 | No Description Available | 1 | piece |
| DCS800-S02-1200-05 | No Description Available | 1 | piece |
| DCS800-S02-1500-04 | No Description Available | 1 | piece |
| DCS800-S02-1500-05 | No Description Available | 1 | piece |
| DCS800-S02-1500-06 | No Description Available | 1 | piece |
| DCS800-S02-1500-07 | No Description Available | 1 | piece |
| DCS800-S02-1900-08 | No Description Available | 1 | piece |
| DCS800-S02-2000-04 | No Description Available | 1 | piece |
| DCS800-S02-2000-05 | No Description Available | 1 | piece |
| DCS800-S02-2050-05 | No Description Available | 1 | piece |
| DCS800-S02-2050-06 | No Description Available | 1 | piece |
| DCS800-S02-2050-07 | No Description Available | 1 | piece |
| DCS800-S02-2500-04 | No Description Available | 1 | piece |
| DCS800-S02-2500-05 | No Description Available | 1 | piece |
| DCS800-S02-2500-06 | No Description Available | 1 | piece |
| DCS800-S02-2500-07 | No Description Available | 1 | piece |
| DCS800-S02-2500-08 | No Description Available | 1 | piece |
| DCS800-S02-3000-04 | No Description Available | 1 | piece |
| DCS800-S02-3000-05 | No Description Available | 1 | piece |
| DCS800-S02-3000-06 | No Description Available | 1 | piece |
| DCS800-S02-3000-07 | No Description Available | 1 | piece |
| DCS800-S02-3000-08 | No Description Available | 1 | piece |
| DCS800-S01-2050-10R | No Description Available | 1 | piece |
| DCS800-S01-2600-10R | No Description Available | 1 | piece |
| DCS800-S01-3300-04R | No Description Available | 1 | piece |
| DCS800-S01-3300-05R | No Description Available | 1 | piece |
| DCS800-S01-3300-06R | No Description Available | 1 | piece |
| DCS800-S01-3300-07R | No Description Available | 1 | piece |
| DCS800-S01-3300-08R | No Description Available | 1 | piece |
| DCS800-S01-3300-10R | No Description Available | 1 | piece |
| DCS800-S01-4000-04R | No Description Available | 1 | piece |
| DCS800-S01-4000-05R | No Description Available | 1 | piece |
| DCS800-S01-4000-06R | No Description Available | 1 | piece |
| DCS800-S01-4000-07R | No Description Available | 1 | piece |
| DCS800-S01-4000-08R | No Description Available | 1 | piece |
| DCS800-S01-4000-10R | No Description Available | 1 | piece |
| DCS800-S01-4800-06R | No Description Available | 1 | piece |
| DCS800-S01-4800-07R | No Description Available | 1 | piece |
| DCS800-S01-4800-08R | No Description Available | 1 | piece |
| DCS800-S01-5200-04R | No Description Available | 1 | piece |
| DCS800-S01-5200-05R | No Description Available | 1 | piece |
| DCS800-S02-2050-10R | No Description Available | 1 | piece |
| DCS800-S02-2600-10R | No Description Available | 1 | piece |
| DCS800-S02-3300-04R | No Description Available | 1 | piece |
| DCS800-S02-3300-05R | No Description Available | 1 | piece |
| DCS800-S02-3300-06R | No Description Available | 1 | piece |
| DCS800-S02-3300-07R | No Description Available | 1 | piece |

| | | | |
|----------------------|--------------------------|---|-------|
| DCS800-S02-3300-08R | No Description Available | 1 | piece |
| DCS800-S02-3300-10R | No Description Available | 1 | piece |
| DCS800-S02-4000-04R | No Description Available | 1 | piece |
| DCS800-S02-4000-05R | No Description Available | 1 | piece |
| DCS800-S02-4000-06R | No Description Available | 1 | piece |
| DCS800-S02-4000-07R | No Description Available | 1 | piece |
| DCS800-S02-4000-08R | No Description Available | 1 | piece |
| DCS800-S02-4000-10R | No Description Available | 1 | piece |
| DCS800-S02-4800-06R | No Description Available | 1 | piece |
| DCS800-S02-4800-07R | No Description Available | 1 | piece |
| DCS800-S02-4800-08R | No Description Available | 1 | piece |
| DCS800-S02-5200-04R | No Description Available | 1 | piece |
| DCS800-S02-5200-05R | No Description Available | 1 | piece |
| DCS800-S01-2050-10L | No Description Available | 1 | piece |
| DCS800-S01-2600-10L | No Description Available | 1 | piece |
| DCS800-S01-3300-04L | No Description Available | 1 | piece |
| DCS800-S01-3300-05L | No Description Available | 1 | piece |
| DCS800-S01-3300-06L | No Description Available | 1 | piece |
| DCS800-S01-3300-07L | No Description Available | 1 | piece |
| DCS800-S01-3300-08L | No Description Available | 1 | piece |
| DCS800-S01-3300-10L | No Description Available | 1 | piece |
| DCS800-S01-4000-04L | No Description Available | 1 | piece |
| DCS800-S01-4000-05L | No Description Available | 1 | piece |
| DCS800-S01-4000-06L | No Description Available | 1 | piece |
| DCS800-S01-4000-07L | No Description Available | 1 | piece |
| DCS800-S01-4000-08L | No Description Available | 1 | piece |
| DCS800-S01-4000-10L | No Description Available | 1 | piece |
| DCS800-S01-4800-06L | No Description Available | 1 | piece |
| DCS800-S01-4800-07L | No Description Available | 1 | piece |
| DCS800-S01-4800-08L | No Description Available | 1 | piece |
| DCS800-S01-5200-04L | No Description Available | 1 | piece |
| DCS800-S01-5200-05L | No Description Available | 1 | piece |
| DCS800-S02-2050-10L | No Description Available | 1 | piece |
| DCS800-S02-2600-10L | No Description Available | 1 | piece |
| DCS800-S02-3300-04L | No Description Available | 1 | piece |
| DCS800-S02-3300-05L | No Description Available | 1 | piece |
| DCS800-S02-3300-06L | No Description Available | 1 | piece |
| DCS800-S02-3300-07L | No Description Available | 1 | piece |
| DCS800-S02-3300-08L | No Description Available | 1 | piece |
| DCS800-S02-3300-10L | No Description Available | 1 | piece |
| DCS800-S02-4000-04L | No Description Available | 1 | piece |
| DCS800-S02-4000-05L | No Description Available | 1 | piece |
| DCS800-S02-4000-06L | No Description Available | 1 | piece |
| DCS800-S02-4000-07L | No Description Available | 1 | piece |
| DCS800-S02-4000-08L | No Description Available | 1 | piece |
| DCS800-S02-4000-10L | No Description Available | 1 | piece |
| DCS800-S02-4800-06L | No Description Available | 1 | piece |
| DCS800-S02-4800-07L | No Description Available | 1 | piece |
| DCS800-S02-4800-08L | No Description Available | 1 | piece |
| DCS800-S02-5200-04L | No Description Available | 1 | piece |
| DCS800-S02-5200-05L | No Description Available | 1 | piece |
| DCS800-S01-0900-06a | No Description Available | 1 | piece |
| DCS800-S01-0900-06-b | No Description Available | 1 | piece |
| DCS800-S01-0900-07a | No Description Available | 1 | piece |

| | | | |
|----------------------|--------------------------|---|-------|
| DCS800-S01-0900-07-b | No Description Available | 1 | piece |
| DCS800-S01-1190-04 | No Description Available | 1 | piece |
| DCS800-S01-1190-05 | No Description Available | 1 | piece |
| DCS800-S01-1200-04a | No Description Available | 1 | piece |
| DCS800-S01-1200-04-b | No Description Available | 1 | piece |
| DCS800-S01-1200-05a | No Description Available | 1 | piece |
| DCS800-S01-1200-05-b | No Description Available | 1 | piece |
| DCS800-S01-1500-04-b | No Description Available | 1 | piece |
| DCS800-S01-1500-05-b | No Description Available | 1 | piece |
| DCS800-S01-1500-06-b | No Description Available | 1 | piece |
| DCS800-S01-1500-07-b | No Description Available | 1 | piece |
| DCS800-S01-1900-08a | No Description Available | 1 | piece |
| DCS800-S01-1900-08-b | No Description Available | 1 | piece |
| DCS800-S01-2000-04-b | No Description Available | 1 | piece |
| DCS800-S01-2000-05-b | No Description Available | 1 | piece |
| DCS800-S01-2000-06-b | No Description Available | 1 | piece |
| DCS800-S01-2000-07-b | No Description Available | 1 | piece |
| DCS800-S01-2050-05a | No Description Available | 1 | piece |
| DCS800-S01-2050-05-b | No Description Available | 1 | piece |
| DCS800-S01-2050-06a | No Description Available | 1 | piece |
| DCS800-S01-2050-06-b | No Description Available | 1 | piece |
| DCS800-S01-2050-07a | No Description Available | 1 | piece |
| DCS800-S01-2050-07-b | No Description Available | 1 | piece |
| DCS800-S01-2050-10-b | No Description Available | 1 | piece |
| DCS800-S01-2500-04-b | No Description Available | 1 | piece |
| DCS800-S01-2500-05-b | No Description Available | 1 | piece |
| DCS800-S01-2500-06-b | No Description Available | 1 | piece |
| DCS800-S01-2500-07-b | No Description Available | 1 | piece |
| DCS800-S01-2500-08-b | No Description Available | 1 | piece |
| DCS800-S01-2600-10-b | No Description Available | 1 | piece |
| DCS800-S01-3000-04-b | No Description Available | 1 | piece |
| DCS800-S01-3000-05-b | No Description Available | 1 | piece |
| DCS800-S01-3000-06-b | No Description Available | 1 | piece |
| DCS800-S01-3000-07-b | No Description Available | 1 | piece |
| DCS800-S01-3000-08-b | No Description Available | 1 | piece |
| DCS800-S01-3300-04-b | No Description Available | 1 | piece |
| DCS800-S01-3300-05-b | No Description Available | 1 | piece |
| DCS800-S01-3300-06-b | No Description Available | 1 | piece |
| DCS800-S01-3300-07-b | No Description Available | 1 | piece |
| DCS800-S01-3300-08-b | No Description Available | 1 | piece |
| DCS800-S01-3300-10-b | No Description Available | 1 | piece |
| DCS800-S01-4000-04-b | No Description Available | 1 | piece |
| DCS800-S01-4000-05-b | No Description Available | 1 | piece |
| DCS800-S01-4000-06-b | No Description Available | 1 | piece |
| DCS800-S01-4000-07-b | No Description Available | 1 | piece |
| DCS800-S01-4000-08-b | No Description Available | 1 | piece |
| DCS800-S01-4000-10-b | No Description Available | 1 | piece |
| DCS800-S01-4800-06-b | No Description Available | 1 | piece |
| DCS800-S01-4800-07-b | No Description Available | 1 | piece |
| DCS800-S01-4800-08-b | No Description Available | 1 | piece |
| DCS800-S01-5200-04-b | No Description Available | 1 | piece |
| DCS800-S01-5200-05-b | No Description Available | 1 | piece |
| DCS800-S02-0650-07 | No Description Available | 1 | piece |
| DCS800-S02-0900-06a | No Description Available | 1 | piece |

| | | | |
|----------------------|--------------------------|---|-------|
| DCS800-S02-0900-06-b | No Description Available | 1 | piece |
| DCS800-S02-0900-07a | No Description Available | 1 | piece |
| DCS800-S02-0900-07-b | No Description Available | 1 | piece |
| DCS800-S02-1190-04 | No Description Available | 1 | piece |
| DCS800-S02-1190-05 | No Description Available | 1 | piece |
| DCS800-S02-1200-04a | No Description Available | 1 | piece |
| DCS800-S02-1200-04-b | No Description Available | 1 | piece |
| DCS800-S02-1200-05a | No Description Available | 1 | piece |
| DCS800-S02-1200-05-b | No Description Available | 1 | piece |
| DCS800-S02-1500-04-b | No Description Available | 1 | piece |
| DCS800-S02-1500-05-b | No Description Available | 1 | piece |
| DCS800-S02-1500-06-b | No Description Available | 1 | piece |
| DCS800-S02-1500-07-b | No Description Available | 1 | piece |
| DCS800-S02-1900-08a | No Description Available | 1 | piece |
| DCS800-S02-1900-08-b | No Description Available | 1 | piece |
| DCS800-S02-2000-04-b | No Description Available | 1 | piece |
| DCS800-S02-2000-05-b | No Description Available | 1 | piece |
| DCS800-S02-2050-05a | No Description Available | 1 | piece |
| DCS800-S02-2050-05-b | No Description Available | 1 | piece |
| DCS800-S02-2050-06a | No Description Available | 1 | piece |
| DCS800-S02-2050-06-b | No Description Available | 1 | piece |
| DCS800-S02-2050-07a | No Description Available | 1 | piece |
| DCS800-S02-2050-07-b | No Description Available | 1 | piece |
| DCS800-S02-2050-10-b | No Description Available | 1 | piece |
| DCS800-S02-2500-04-b | No Description Available | 1 | piece |
| DCS800-S02-2500-05-b | No Description Available | 1 | piece |
| DCS800-S02-2500-06-b | No Description Available | 1 | piece |
| DCS800-S02-2500-07-b | No Description Available | 1 | piece |
| DCS800-S02-2500-08-b | No Description Available | 1 | piece |
| DCS800-S02-2600-10-b | No Description Available | 1 | piece |
| DCS800-S02-3000-04-b | No Description Available | 1 | piece |
| DCS800-S02-3000-05-b | No Description Available | 1 | piece |
| DCS800-S02-3000-06-b | No Description Available | 1 | piece |
| DCS800-S02-3000-07-b | No Description Available | 1 | piece |
| DCS800-S02-3000-08-b | No Description Available | 1 | piece |
| DCS800-S02-3300-04-b | No Description Available | 1 | piece |
| DCS800-S02-3300-05-b | No Description Available | 1 | piece |
| DCS800-S02-3300-06-b | No Description Available | 1 | piece |
| DCS800-S02-3300-07-b | No Description Available | 1 | piece |
| DCS800-S02-3300-08-b | No Description Available | 1 | piece |
| DCS800-S02-3300-10-b | No Description Available | 1 | piece |
| DCS800-S02-4000-04-b | No Description Available | 1 | piece |
| DCS800-S02-4000-05-b | No Description Available | 1 | piece |
| DCS800-S02-4000-06-b | No Description Available | 1 | piece |
| DCS800-S02-4000-07-b | No Description Available | 1 | piece |
| DCS800-S02-4000-08-b | No Description Available | 1 | piece |
| DCS800-S02-4000-10-b | No Description Available | 1 | piece |
| DCS800-S02-4800-06-b | No Description Available | 1 | piece |
| DCS800-S02-4800-07-b | No Description Available | 1 | piece |
| DCS800-S02-4800-08-b | No Description Available | 1 | piece |
| DCS800-S02-5200-04-b | No Description Available | 1 | piece |
| DCS800-S02-5200-05-b | No Description Available | 1 | piece |

Product specific part data

| Product | Category | Drive Part Category |
|--------------------|-----------------|---------------------------------------|
| DCS800-S01-0020-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0020-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0045-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0045-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0065-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0065-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0090-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0090-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0125-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0125-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0180-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0180-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0230-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0230-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0290-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0315-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0315-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0405-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0405-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0470-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0470-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0590-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0610-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0610-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0740-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0740-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0900-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0900-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0900-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0900-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1200-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1200-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1500-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1500-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1500-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1500-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1900-08 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2000-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2000-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2000-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2000-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-07 | DCS800-S | Boards, Control Units, Power Supplies |

| Product | Category | Drive Part Category |
|--------------------|-----------------|---------------------------------------|
| DCS800-S01-2500-08 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-08 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0025-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0025-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0050-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0050-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0075-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0075-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0100-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0100-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0140-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0140-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0200-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0200-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0260-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0260-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0320-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0350-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0350-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0450-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0450-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0520-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0520-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0650-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0680-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0680-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0820-04 | | Boards, Control Units, Power Supplies |
| DCS800-S02-0820-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1000-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1000-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0900-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0900-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1200-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1200-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1500-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1500-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1500-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1500-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1900-08 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2000-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2000-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-06 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-08 | DCS800-S | Boards, Control Units, Power Supplies |

| Product | Category | Drive Part Category |
|----------------------|-----------------|---------------------------------------|
| DCS800-S01-4000-06L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-07L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-08L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-10L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4800-06L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4800-07L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4800-08L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-5200-04L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-5200-05L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-10L | | Boards, Control Units, Power Supplies |
| DCS800-S02-2600-10L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-04L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-05L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-06L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-07L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-08L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-10L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-04L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-05L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-06L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-07L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-08L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-10L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4800-06L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4800-07L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4800-08L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-5200-04L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-5200-05L | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0900-06a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0900-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0900-07a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-0900-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1190-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1190-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1200-04a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1200-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1200-05a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1200-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1500-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1500-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1500-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1500-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1900-08a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-1900-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2000-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2000-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2000-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2000-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-05a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-06a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-07a | DCS800-S | Boards, Control Units, Power Supplies |

| Product | Category | Drive Part Category |
|----------------------|-----------------|---------------------------------------|
| DCS800-S01-2050-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2050-10-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2500-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-2600-10-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3000-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3300-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3300-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3300-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3300-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3300-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-3300-10-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4000-10-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4800-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4800-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-4800-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-5200-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S01-5200-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0650-07 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0900-06a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0900-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0900-07a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-0900-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1190-04 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1190-05 | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1200-04a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1200-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1200-05a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1200-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1500-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1500-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1500-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1500-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1900-08a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-1900-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2000-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2000-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-05a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-06a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-06-b | DCS800-S | Boards, Control Units, Power Supplies |

| Product | Category | Drive Part Category |
|----------------------|----------|---------------------------------------|
| DCS800-S02-2050-07a | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2050-10-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2500-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-2600-10-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3000-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3000-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3000-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3000-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3000-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-3300-10-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-05-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4000-10-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4800-06-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4800-07-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-4800-08-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-5200-04-b | DCS800-S | Boards, Control Units, Power Supplies |
| DCS800-S02-5200-05-b | DCS800-S | Boards, Control Units, Power Supplies |

Categories

Drives → DC Drives → Industrial Drives → Modules → DCS800-S

Drives → DC Drives → Industrial Drives → Retrofit Solutions → DCS800-R Rebuilt Kit

Drives → Services → Spares and Consumables → Parts

