



 PRODUCT-DETAILS

3ADT751010P0003

LT 2032 2500/1A; CURRENT TRANSFORMER



General Information

Product ID	3ADT751010P0003
ABB Type Designation	LT 2032 2500/1A
Catalog Description	LT 2032 2500/1A; CURRENT TRANSFORMER
Long Description	LT 2032 2500/1A

Additional Information

ABB Type Designation	LT 2032 2500/1A
CN8	85043129
Country or Territory of Origin	United States Germany India
Customs Tariff Number	85043129
Frame Size	Undefined
Gross Volume	0.792 dm ³
Gross Weight	1.7 kg
HS Code	850431 -- ELECTRICAL MACHINERY AND EQUIPMENT AND PARTS THEREOF; SOUND RECORDERS AND REPRODUCERS, TELEVISION IMAGE AND SOUND RECORDERS AND REPRODUCERS, AND PARTS AND

ACCESSORIES OF SUCH ARTICLES;Electrical transformers, static converters (for example, rectifiers) and inductors;Other transformers;Having a power handling capacity not exceeding 1kVA

Invoice Description	CURRENT TRANSFORMER
Made To Order	No
Minimum Order Quantity	1 piece
Order Multiple	1 piece
Package Level 1 Depth / Length	120 mm
Package Level 1 Gross Weight	1.7 kg
Package Level 1 Height	50 mm
Package Level 1 Units	1 piece
Package Level 1 Width	132 mm
Part Type	New
Product Name	CURRENT TRANSFORMER
Product Net Depth / Length	120 mm
Product Net Height	50 mm
Product Net Weight	1.7 kg
Product Net Width	132 mm
Product Type	Spare_Parts
Quote Only	No
Replaced Product ID (OLD)	3ADT751010P0001
Selling Unit of Measure	piece
Stocked At (Warehouses)	Wickliffe, Ohio, United States Finland Menden, Germany New Berlin,Wisconsin, United States Beijing, China Singapore, Singapore Dubai, United Arab Emirates Tokyo, Japan Santiago, Chile Finland Bangalore, India
Technical Information	1500;prated primary current: 3000A;rated
WEEE Category	Product Not in WEEE Scope

Where Used (as a spare part for "Products")

Identifier	Description	Quantity	Unit Of Measure
DCS800-S01-0900-06	No Description Available	1	piece
DCS800-S01-0900-07	No Description Available	1	piece
DCS800-S01-1200-04	No Description Available	1	piece
DCS800-S01-1200-05	No Description Available	1	piece
DCS800-S01-1500-04	No Description Available	1	piece
DCS800-S01-1500-05	No Description Available	1	piece
DCS800-S01-1500-06	No Description Available	1	piece
DCS800-S01-1500-07	No Description Available	1	piece

DCS800-S01-1900-08	No Description Available	1	piece
DCS800-S01-2000-04	No Description Available	1	piece
DCS800-S01-2000-05	No Description Available	1	piece
DCS800-S01-2000-06	No Description Available	1	piece
DCS800-S01-2000-07	No Description Available	1	piece
DCS800-S01-2050-05	No Description Available	1	piece
DCS800-S01-2050-06	No Description Available	1	piece
DCS800-S01-2050-07	No Description Available	1	piece
DCS800-S01-2500-04	No Description Available	1	piece
DCS800-S01-2500-05	No Description Available	1	piece
DCS800-S01-2500-06	No Description Available	1	piece
DCS800-S01-2500-07	No Description Available	1	piece
DCS800-S01-2500-08	No Description Available	1	piece
DCS800-S01-3000-04	No Description Available	1	piece
DCS800-S01-3000-05	No Description Available	1	piece
DCS800-S01-3000-06	No Description Available	1	piece
DCS800-S01-3000-07	No Description Available	1	piece
DCS800-S01-3000-08	No Description Available	1	piece
DCS800-S02-0900-06	No Description Available	1	piece
DCS800-S02-0900-07	No Description Available	1	piece
DCS800-S02-1200-04	No Description Available	1	piece
DCS800-S02-1200-05	No Description Available	1	piece
DCS800-S02-1500-04	No Description Available	1	piece
DCS800-S02-1500-05	No Description Available	1	piece
DCS800-S02-1500-06	No Description Available	1	piece
DCS800-S02-1500-07	No Description Available	1	piece
DCS800-S02-1900-08	No Description Available	1	piece
DCS800-S02-2000-04	No Description Available	1	piece
DCS800-S02-2000-05	No Description Available	1	piece
DCS800-S02-2050-05	No Description Available	1	piece
DCS800-S02-2050-06	No Description Available	1	piece
DCS800-S02-2050-07	No Description Available	1	piece
DCS800-S02-2500-04	No Description Available	1	piece
DCS800-S02-2500-05	No Description Available	1	piece
DCS800-S02-2500-06	No Description Available	1	piece
DCS800-S02-2500-07	No Description Available	1	piece
DCS800-S02-2500-08	No Description Available	1	piece
DCS800-S02-3000-04	No Description Available	1	piece
DCS800-S02-3000-05	No Description Available	1	piece
DCS800-S02-3000-06	No Description Available	1	piece
DCS800-S02-3000-07	No Description Available	1	piece
DCS800-S02-3000-08	No Description Available	1	piece
DCS880-S01-0900-06X0	No Description Available	1	piece
DCS880-S01-0900-07X0	No Description Available	1	piece
DCS880-S02-0900-06X0	No Description Available	1	piece
DCS880-S02-0900-07X0	No Description Available	1	piece
DCS880-S01-1200-04X0	No Description Available	1	piece
DCS880-S01-1200-05X0	No Description Available	1	piece
DCS880-S02-1200-04X0	No Description Available	1	piece
DCS880-S02-1200-05X0	No Description Available	1	piece
DCS880-S01-1500-04X0	No Description Available	1	piece
DCS880-S01-1500-05X0	No Description Available	1	piece
DCS880-S01-1500-06X0	No Description Available	1	piece
DCS880-S01-1500-07X0	No Description Available	1	piece

DCS880-S02-1500-04X0	No Description Available	1	piece
DCS880-S02-1500-05X0	No Description Available	1	piece
DCS880-S02-1500-06X0	No Description Available	1	piece
DCS880-S02-1500-07X0	No Description Available	1	piece
DCS880-S01-2000-04X0	No Description Available	1	piece
DCS880-S01-2000-05X0	No Description Available	1	piece
DCS880-S01-2000-06X0	No Description Available	1	piece
DCS880-S01-2000-07X0	No Description Available	1	piece
DCS880-S02-2000-04X0	No Description Available	1	piece
DCS880-S02-2000-05X0	No Description Available	1	piece
DCS800-S01-0900-06a	No Description Available	1	piece
DCS800-S01-0900-06-b	No Description Available	1	piece
DCS800-S01-0900-07a	No Description Available	1	piece
DCS800-S01-0900-07-b	No Description Available	1	piece
DCS800-S01-1200-04a	No Description Available	1	piece
DCS800-S01-1200-04-b	No Description Available	1	piece
DCS800-S01-1200-05a	No Description Available	1	piece
DCS800-S01-1200-05-b	No Description Available	1	piece
DCS800-S01-1500-04-b	No Description Available	1	piece
DCS800-S01-1500-05-b	No Description Available	1	piece
DCS800-S01-1500-06-b	No Description Available	1	piece
DCS800-S01-1500-07-b	No Description Available	1	piece
DCS800-S01-1900-08a	No Description Available	1	piece
DCS800-S01-1900-08-b	No Description Available	1	piece
DCS800-S01-2000-04-b	No Description Available	1	piece
DCS800-S01-2000-05-b	No Description Available	1	piece
DCS800-S01-2000-06-b	No Description Available	1	piece
DCS800-S01-2000-07-b	No Description Available	1	piece
DCS800-S01-2050-05a	No Description Available	1	piece
DCS800-S01-2050-05-b	No Description Available	1	piece
DCS800-S01-2050-06a	No Description Available	1	piece
DCS800-S01-2050-06-b	No Description Available	1	piece
DCS800-S01-2050-07a	No Description Available	1	piece
DCS800-S01-2050-07-b	No Description Available	1	piece
DCS800-S01-2500-04-b	No Description Available	1	piece
DCS800-S01-2500-05-b	No Description Available	1	piece
DCS800-S01-2500-06-b	No Description Available	1	piece
DCS800-S01-2500-07-b	No Description Available	1	piece
DCS800-S01-2500-08-b	No Description Available	1	piece
DCS800-S01-3000-04-b	No Description Available	1	piece
DCS800-S01-3000-05-b	No Description Available	1	piece
DCS800-S01-3000-06-b	No Description Available	1	piece
DCS800-S01-3000-07-b	No Description Available	1	piece
DCS800-S01-3000-08-b	No Description Available	1	piece
DCS800-S02-0900-06a	No Description Available	1	piece
DCS800-S02-0900-06-b	No Description Available	1	piece
DCS800-S02-0900-07a	No Description Available	1	piece
DCS800-S02-0900-07-b	No Description Available	1	piece
DCS800-S02-1200-04a	No Description Available	1	piece
DCS800-S02-1200-04-b	No Description Available	1	piece
DCS800-S02-1200-05a	No Description Available	1	piece
DCS800-S02-1200-05-b	No Description Available	1	piece
DCS800-S02-1500-04-b	No Description Available	1	piece
DCS800-S02-1500-05-b	No Description Available	1	piece

DCS800-S02-1500-06-b	No Description Available	1	piece
DCS800-S02-1500-07-b	No Description Available	1	piece
DCS800-S02-1900-08a	No Description Available	1	piece
DCS800-S02-1900-08-b	No Description Available	1	piece
DCS800-S02-2000-04-b	No Description Available	1	piece
DCS800-S02-2000-05-b	No Description Available	1	piece
DCS800-S02-2050-05a	No Description Available	1	piece
DCS800-S02-2050-05-b	No Description Available	1	piece
DCS800-S02-2050-06a	No Description Available	1	piece
DCS800-S02-2050-06-b	No Description Available	1	piece
DCS800-S02-2050-07a	No Description Available	1	piece
DCS800-S02-2050-07-b	No Description Available	1	piece
DCS800-S02-2500-04-b	No Description Available	1	piece
DCS800-S02-2500-05-b	No Description Available	1	piece
DCS800-S02-2500-06-b	No Description Available	1	piece
DCS800-S02-2500-07-b	No Description Available	1	piece
DCS800-S02-2500-08-b	No Description Available	1	piece
DCS800-S02-3000-04-b	No Description Available	1	piece
DCS800-S02-3000-05-b	No Description Available	1	piece
DCS800-S02-3000-06-b	No Description Available	1	piece
DCS800-S02-3000-07-b	No Description Available	1	piece
DCS800-S02-3000-08-b	No Description Available	1	piece
DCS880-S01-1900-08X0	No Description Available	1	piece
DCS880-S01-2050-05X0	No Description Available	1	piece
DCS880-S01-2050-06X0	No Description Available	1	piece
DCS880-S01-2050-07X0	No Description Available	1	piece
DCS880-S01-2500-04X0	No Description Available	1	piece
DCS880-S01-2500-05X0	No Description Available	1	piece
DCS880-S01-2500-06X0	No Description Available	1	piece
DCS880-S01-2500-07X0	No Description Available	1	piece
DCS880-S01-2500-08X0	No Description Available	1	piece
DCS880-S01-3000-04X0	No Description Available	1	piece
DCS880-S01-3000-05X0	No Description Available	1	piece
DCS880-S01-3000-06X0	No Description Available	1	piece
DCS880-S01-3000-07X0	No Description Available	1	piece
DCS880-S01-3000-08X0	No Description Available	1	piece
DCS880-S02-1900-08X0	No Description Available	1	piece
DCS880-S02-2050-05X0	No Description Available	1	piece
DCS880-S02-2050-06X0	No Description Available	1	piece
DCS880-S02-2050-07X0	No Description Available	1	piece
DCS880-S02-2500-04X0	No Description Available	1	piece
DCS880-S02-2500-05X0	No Description Available	1	piece
DCS880-S02-2500-06X0	No Description Available	1	piece
DCS880-S02-2500-07X0	No Description Available	1	piece
DCS880-S02-2500-08X0	No Description Available	1	piece
DCS880-S02-3000-04X0	No Description Available	1	piece
DCS880-S02-3000-05X0	No Description Available	1	piece
DCS880-S02-3000-06X0	No Description Available	1	piece
DCS880-S02-3000-07X0	No Description Available	1	piece
DCS880-S02-3000-08X0	No Description Available	1	piece
DCS880-S01-1900-08XA	No Description Available	1	piece
DCS880-S01-2050-05XA	No Description Available	1	piece
DCS880-S01-2050-06XA	No Description Available	1	piece
DCS880-S01-2050-07XA	No Description Available	1	piece

DCS880-S01-2500-04XA	No Description Available	1	piece
DCS880-S01-2500-05XA	No Description Available	1	piece
DCS880-S01-2500-06XA	No Description Available	1	piece
DCS880-S01-2500-07XA	No Description Available	1	piece
DCS880-S01-2500-08XA	No Description Available	1	piece
DCS880-S01-3000-04XA	No Description Available	1	piece
DCS880-S01-3000-05XA	No Description Available	1	piece
DCS880-S01-3000-06XA	No Description Available	1	piece
DCS880-S01-3000-07XA	No Description Available	1	piece
DCS880-S01-3000-08XA	No Description Available	1	piece
DCS880-S02-1900-08XA	No Description Available	1	piece
DCS880-S02-2050-05XA	No Description Available	1	piece
DCS880-S02-2050-06XA	No Description Available	1	piece
DCS880-S02-2050-07XA	No Description Available	1	piece
DCS880-S02-2500-04XA	No Description Available	1	piece
DCS880-S02-2500-05XA	No Description Available	1	piece
DCS880-S02-2500-06XA	No Description Available	1	piece
DCS880-S02-2500-07XA	No Description Available	1	piece
DCS880-S02-2500-08XA	No Description Available	1	piece
DCS880-S02-3000-04XA	No Description Available	1	piece
DCS880-S02-3000-05XA	No Description Available	1	piece
DCS880-S02-3000-06XA	No Description Available	1	piece
DCS880-S02-3000-07XA	No Description Available	1	piece
DCS880-S02-3000-08XA	No Description Available	1	piece
DCT880-W03-1300-04	No Description Available	1	piece
DCT880-W03-1300-05	No Description Available	1	piece
DCT880-W03-1300-07	No Description Available	1	piece
DCT880-W03-1750-04	No Description Available	1	piece
DCT880-W03-1750-05	No Description Available	1	piece
DCT880-W03-1750-07	No Description Available	1	piece

Product specific part data

Product	Category	Drive Part Category
DCS800-S01-0900-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1900-08	DCS800-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS800-S01-2000-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1900-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2000-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2000-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-06	DCS800-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS800-S02-2050-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-04	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-05	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-06	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-07	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-08	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-0900-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-0900-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-0900-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-0900-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1200-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1200-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1200-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1200-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1500-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1500-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1500-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1500-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1500-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1500-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1500-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1500-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2000-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2000-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2000-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS880-S01-2000-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2000-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2000-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-06a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-07a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-0900-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-04a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-05a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1200-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1500-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1900-08a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-1900-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2000-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-05a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-06a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-07a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2050-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS800-S01-2500-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-2500-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S01-3000-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-06a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-07a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-0900-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-04a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-05a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1200-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1500-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1900-08a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-1900-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2000-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2000-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-05a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-06a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-07a	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2050-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS800-S02-2500-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-2500-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-04-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-05-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-06-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-07-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS800-S02-3000-08-b	DCS800-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1900-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1900-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS880-S02-2500-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-04X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-05X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-06X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-07X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-08X0	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-1900-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2050-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-04XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-2500-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-04XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S01-3000-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-1900-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2050-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-04XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-2500-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)

Product	Category	Drive Part Category
DCS880-S02-3000-04XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-05XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-06XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-07XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCS880-S02-3000-08XA	DCS880-S	Transformers, Transducers (Voltage, Current)
DCT880-W03-1300-04	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1300-05	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1300-07	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1750-04	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1750-05	DCT880-W	Transformers, Transducers (Voltage, Current)
DCT880-W03-1750-07	DCT880-W	Transformers, Transducers (Voltage, Current)

Categories

Drives → DC Drives → Industrial Drives → Modules → DCS800-S

Drives → DC Drives → Industrial Drives → Modules → DCS880-S

Drives → Services → Spares and Consumables → Parts

Power Converters and Controllers → Power Controllers → Modules → DCT880-W

