ſ


© 5,3 30 30 M20 x 1,5			
Type code	NI35-CP40-Y1X/S100		
Ident no.	1011125		
Rated operating distance Sn	35 mm		
Mounting condition	non-flush		
Assured sensing range	\leq (0,81 x Sn) mm St37 = 1; Al = 0.3; stainless steel = 0.7; Ms = 0.4 \leq 2 % of full scale		
Correction factors			
Repeatability			
emperature drift	10 %		
La transfe	≤ ± 20 %, ≥ +70 °C		
Hysteresis	110 %		
Ambient temperature	-25+100 °C in the explosion hazardous area see instruction leaflet		
Output function	2-wire, NAMUR		
Switching frequency	0.08 kHz		
Voltage	Nom. 8.2 VDC		
Non-actuated current consumption	≥ 2.1 mA		
Actuated current consumption	≤ 1.2 mA		
Approval acc. to	KEMA 02 ATEX 1090X		
Internal capacitance (C _i) / inductance (L _i)	250 nF / 350 μH		
Device designation	(iii) II 2 G Ex ia IIC T6 Gb / II 1 D Ex ia IIIC T95 °C Da (max. U, = 20 V, I, = 60 mA, P, = 200 mW)		
Warning	avoid static charging		
Design	rectangular, CP40		
Dimensions	114 x 40 x 40 mm		
Housing material	plastic, PBT, black		
Connection Clamping ability	terminal chamber		
Vibration resistance	≤ 2.5 mm² 55 Hz (1 mm)		
	30 g (11 ms)		
Snock resistance			
Shock resistance Protection class	IP67		

Switching state



- ATEX category II 2 G. Ex zone 1
- ATEX category II 1 D, Ex zone 20 at temperatures up to +70°C
- SIL2 according to IEC 61508
- Rectangular, height 40 mm
- Variable orientation of active face in 9 directions
- Plastic, PBT-GF30-V0
- For temperatures up to +100 °C
- DC 2-wire, nom. 8.2 VDC
- Output acc. to DIN EN 60947-5-6 (NA-MUR)
- Terminal chamber

Wiring diagram



Functional principle

Inductive sensors detect metal objects contactless and wear-free. For this purpose they use a high-frequency electromagnetic AC field that interacts with the target. The sensors hosting a ferrite core coil generate the AC field through an LC resonant circuit.


Special versions are available for ambient temperatures between -60°C and +250°C.

LED yellow

Distance D	4.5 x B	
Distance W	3 x Sn	
Distance S	1.5 x B	
Distance G	6 x Sn	
Distance N	1 x B	

Width of the active face B

40 mm







Industri<mark>al Automation</mark>

TURCK

Accessories

Type code	Ident no.	Description	Dimension drawing
Adjusting bar JS 025/037	69429	Adjusting bar for rectangular housings CK/CP40; material: VA	0 5.3 0 5.3 0 70 100 5
BSS-CP40	6901318	Mounting bracket for rectangular devices; material: Polypropylene	
IM1-22EX-R	7541231	Isolating switching amplifier, dual-channel; 2 relay outputs NO; input NAMUR signal; selectable ON/OFF mode for wire- break and short-circuit monitoring; adjustable signal flow (NO/ NC mode); removable terminal blocks; 18 mm width; universal voltage supply unit	



Operating manual

Intended use

This device fulfills the directive 94/9/EC and is suited for use in explosion hazardous areas according to EN60079-0:2012, -11:2012, -26:2007. Further it is suited for use in safety-related systems, including SIL2 as per IEC 61508.

In order to ensure correct operation to the intended purpose it is required to observe the national regulations and directives.

For use in explosion hazardous areas conform to classification

II 2 G and II 1 D (Group II, Category 2 G, electrical equipment for gaseous atmospheres and category 1 D, electrical equipment for dust atmospheres).

Marking (see device or technical data sheet)

🐵 II 2 G acc. to Ex ia IIC T6 Gb acc. to EN60079-0 and -26 und 🐵 II 1 D Ex ia IIIC T95°C Da acc. to EN60079-0

Local admissible ambient temperature

as ATEX category II 2 G electrical equipment -25...+100 °C, as category II 1 D -25...+70 °C. The corresponding temperature classes are provided in the ATEX type-examination certificate.

Installation / Commissioning

These devices may only be installed, connected and operated by trained and qualified staff. Qualified staff must have knowledge of protection classes, directives and regulations concerning electrical equipment designed for use in explosion hazardous areas. Please verify that the classification and the marking on the device comply with the actual application conditions.

This device is only suited for connection to approved Exi circuits compliant to EN60079-0 and -11. Please observe the maximum admissible electrical values.

After connection to other circuits the sensor may no longer be used in Exi installations. When interconnected to (associated) electrical equipment, it is required to perform the "Proof of intrinsic safety" (EN60079-14).

When employed in safety systems to IEC 51408 it is required to assess the failure probability (PFD) of the complete circuitry.

Installation and mounting instructions

Avoid static charging of cables and plastic devices. Please only clean the device with a damp cloth. Do not install the device in a dust flow and avoid build-up of dust deposits on the device.

If the devices and the cable could be subject to mechanical damage, they must be protected accordingly. They must also be shielded against strong electro-magnetic fields.

The pin configuration and the electrical specifications can be taken from the device marking or the technical data sheet.

In order to avoid contamination of the device, please remove possible blanking plugs of the cable glands or connectors only shortly before inserting the cable or opening the cable socket.

Special conditions for safe operation

avoid static charging

service / maintenance

Repairs are not possible. The approval expires if the device is repaired or modified by a person other than the manufacturer. The most important data from the approval are listed.