## SIEMENS

## Data sheet

## 3RA2210-0DS15-2BB4



Load feeder fuseless, Reversing duty 400 V AC, Size S00 0.22...0.32 A 24 V DC Spring-type terminal for 60 mm busbar systems (also fulfills type of coordination 1) Type of coordination 2, Iq = 150 kA 1 NC (contactor) Adapter length 200 mm

product brand name	SIRIUS
product designation	Reversing starter
design of the product	for 60 mm busbars
product type designation	3RA22
manufacturer's article number	
<ul> <li>of the supplied contactor</li> </ul>	<u>3RT2015-2BB42</u>
<ul> <li>of the supplied circuit-breakers</li> </ul>	<u>3RV2011-0DA20</u>
<ul> <li>of the supplied RS assembly kit</li> </ul>	8US1250-5AS10
<ul> <li>of the supplied busbar adapter</li> </ul>	8US1251-5DS11
<ul> <li>of the supplied link module</li> </ul>	<u>3RA2911-2AA00</u>
<ul> <li>of the supplied wiring kit</li> </ul>	<u>3RA2913-2AA2</u>
General technical data	
size of the circuit-breaker	S00
size of load feeder	S00
power loss [W] for rated value of the current	
<ul> <li>at AC in hot operating state per pole</li> </ul>	2 W
<ul> <li>without load current share typical</li> </ul>	4 W
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
degree of protection NEMA rating	other
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (operating cycles) of contactor typical	30 000 000
type of assignment	2
reference code according to IEC 81346-2:2019	Q
Substance Prohibitance (Date)	10/01/2009
SVHC substance name	Lead - 7439-92-1
Weight	1.907 kg
Ambient conditions	
ambient temperature	
<ul> <li>during operation</li> </ul>	-20 +60 °C
during storage	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current- dependent overload release	0.22 0.32 A
operating voltage	

	600.1/		
rated value	690 V		
• at AC-3 rated value maximum	690 V		
at AC-3e rated value maximum	690 V		
operating frequency rated value	50 60 Hz		
operational current			
• at AC-3 at 400 V rated value	0.32 A		
• at AC-3e at 400 V rated value	0.32 A		
operating power			
• at AC-3			
— at 400 V rated value	90 W		
• at AC-3e			
— at 400 V rated value	90 W		
Control circuit/ Control			
type of voltage of the control supply voltage	DC		
control supply voltage at DC rated value	24 V		
holding power of magnet coil at DC	4 W		
Auxiliary circuit			
product extension auxiliary switch	Yes		
Protective and monitoring functions			
trip class	CLASS 10		
design of the overload release	thermal (bimetallic)		
response value current of instantaneous short-circuit trip unit	4.2 A		
UL/CSA ratings			
full-load current (FLA) for 3-phase AC motor			
• at 480 V rated value	0.32 A		
• at 600 V rated value	0.32 A		
Short-circuit protection			
product function short circuit protection	Yes		
design of the short-circuit trip	magnetic		
conditional short-circuit current (lq)			
	150 000 A		
• at 400 V according to IEC 60947-4-1 rated value	100 000 A		
at 400 V according to IEC 60947-4-1 rated value Installation/ mounting/ dimensions			
Installation/ mounting/ dimensions	vertical		
Installation/ mounting/ dimensions mounting position			
Installation/ mounting/ dimensions mounting position fastening method	vertical		
Installation/ mounting/ dimensions mounting position	vertical for snapping onto 60 mm busbar systems		
Installation/ mounting/ dimensions mounting position fastening method height width	vertical for snapping onto 60 mm busbar systems 230 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm 0 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm 0 mm 50 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — backwards — upwards — at the side — downwards • for live parts — forwards	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — forwards — backwards — backwards — backwards — backwards	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm         32 mm         0 mm         50 mm         10 mm         0 mm         32 mm         0 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards • for live parts — forwards — backwards — upwards — upwards — upwards — upwards — upwards — backwards — upwards — upwards	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm         32 mm         0 mm         50 mm         10 mm         50 mm         10 mm         50 mm         0 mm         50 mm         10 mm         50 mm         0 mm         50 mm         10 mm         90 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — downwards • downwards • downwards — downwards — backwards — downwards — downwards — backwards — backwards — downwards — backwards — backwards — backwards — backwards — backwards — downwards	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 10 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — backwards — at the side — downwards • for live parts — forwards • for live parts — forwards — backwards — at the side — downwards — the side — downwards — backwards — backwards — at the side — downwards — at the side — downwards — at the side — downwards — at the side	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 10 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards • for live parts — forwards — backwards — backwards — upwards — the side — downwards — the side — downwards — at the side — downwards — at the side — downwards — at the side <b>Connections/ Terminals</b>	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards • for live parts — forwards — backwards — backwards — upwards — the side — downwards — the side — downwards — the side <b>Connections/ Terminals</b> type of electrical connection • for main current circuit	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm         32 mm         0 mm         50 mm         10 mm         10 mm         10 mm         32 mm         orm         50 mm         10 mm         32 mm         orm         50 mm         10 mm         50 mm         10 mm         50 mm         10 mm         50 mm         10 mm         spring-loaded terminals		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — backwards — upwards — the side — downwards — the side — downwards — backwards — upwards — at the side <b>Connections/ Terminals</b> type of electrical connection • for main current circuit • for auxiliary and control circuit	vertical for snapping onto 60 mm busbar systems 230 mm 90 mm 155 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — downwards — the side — downwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm         32 mm         spring-loaded terminals         spring-loaded terminals		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — backwards — downwards — backwards — upwards — backwards — backwards — backwards — backwards — backwards — ofor wards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data product function suitable for safety function	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm         32 mm         0 mm         50 mm         10 mm         10 mm         10 mm         32 mm         orm         50 mm         10 mm         32 mm         orm         50 mm         10 mm         50 mm         10 mm         50 mm         10 mm         50 mm         10 mm         spring-loaded terminals		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — at the side <b>Connections/ Terminals</b> type of electrical connection • for main current circuit • for auxiliary and control circuit <b>Safety related data</b> product function suitable for safety function Electrical Safety	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm         spring-loaded terminals         spring-loaded terminals         Yes		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — backwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data product function suitable for safety function Electrical Safety touch protection on the front according to IEC 60529	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm         50 mm         10 mm         50 mm         10 mm         spring-loaded terminals         spring-loaded terminals		
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — at the side <b>Connections/ Terminals</b> type of electrical connection • for main current circuit • for auxiliary and control circuit <b>Safety related data</b> product function suitable for safety function Electrical Safety	vertical         for snapping onto 60 mm busbar systems         230 mm         90 mm         155 mm         32 mm         0 mm         50 mm         10 mm         spring-loaded terminals         spring-loaded terminals         Yes		

<ul> <li>PROFINET IO pr</li> </ul>	rotocol	No			
<ul> <li>PROFIsafe proto</li> </ul>	col	No			
protocol is supported A	S-Interface protocol	No			
Approvals Certificates					
General Product App	roval				For use in hazard- ous locations
CE EG-Konf.	UK CA	<u>Confirmation</u>	(UL)	EHC	KEx ATEX
Test Certificates		Marine / Shipping			
Type Test Certific- ates/Test Report	Special Test Certific- ate	ABS	BUREAU VERITAS		Llovd's Kegister us
Marine / Shipping			other	Dangerous goods	Environment
PRS	RINA	KARS RARS	Confirmation	Transport Information	Environmental Con- firmations

Information on the packaging

https://support.industry.siemens.com/cs/ww/en/view/109813875

Information- and Downloadcenter (Catalogs, Brochures,...)

htt siemens.com/ic10

Industry Mall (Online ordering system) https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2210-0DS15-2BB4

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RA2210-0DS15-2BB4

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://suppo t.industry.siemens.com/cs/ww/en/ps/3RA2210-0DS15 PRR4


Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...) http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RA2210-0DS15-2BB4&lang=en


Characteristic: Tripping characteristics, I2t, Let-through current


https://support.industry.siemens.com/cs/ww/en/ps/3RA2210-0DS15-2BB4/char


Further characteristics (e.g. electrical endurance, switching frequency)

3RA2210-0DS15-2BB4&objecttype=14&gridview=view1 http://www.automation.siemens.com/bilddb/index.aspx?view=









last modified:

6/5/2024 🖸